


# HIK-CONNECT – EDITING ALARM USERS AND PIN CODES VIA THE HIK-CONNECT APP

## NOTE 1: TILE VIEW


This manual is presented in 'Tile View', if you are using the app in 'List View', you can change to 'Tile View' using this button.




## NOTE 2: REFRESH

Always 'drag the screen down and release' to refresh the page and get the latest status/information from the alarm panel.

## PART 1: ENTER THE SETTINGS MENU OF THE ALARM




## PAT 2: ENTER THE 'USER MANAGEMENT' > 'USER' MENU



**NOTE: WHICH USERS YOU CAN EDIT DEPENDS ON IF YOU ARE THE 'MASTER' OR 'SHARED' USER**

	<u>Master User</u>	<u>Shared User</u>
Change their own PIN	Yes	Yes
Change other 'Shared Users' PINs	No	No
Change other 'General User' PINs	Yes	No
Create new 'General Users'	Yes	No
Delete 'General Users'	Yes	No

**PART 3: TO ADD A NEW 'GENERAL USER', CLICK THE '+' ICON IN THE TOP RIGHT CORNER**



**PART 5: THE PIN CODE IS KNOWN AS 'KEYPAD PASSWORD' IN THE APP. TO CHANGE YOUR PIN, CLICK 'CHANGE KEYPAD PASSWORD'**

