


SADP TOOL – HOW TO DOWNLOAD AND INSTALL SADP TOOL

PART 1: DOWNLOAD THE SOFTWARE


Go to Google search.

Search for 'SADP tool for windows'.



Click on the search result.

Ensure the search result is for 'SADP' and is on the 'Hikvision AU' website.



Download the software.

<https://www.hikvision.com/au-en/support/tools/hitools/clea8b3e4ea7da90a9/>

HIKVISION Products Solutions Support Partners

[Back to HITools list](#)

SADP
 V3.1.2.1 | 62.88MB | 2023/12/08

[Download](#)

SADP software is used for searching the online devices in the same network. It supports viewing the device information, activating the device, editing the network parameters of the device and resetting the device password, etc.

SADP

Total number of online devices: **37**

ID	Device Type	Status	IP Address	Port	Enhanced SDK Service Port	Software Version	IPv4 Gateway
001	DS-45071-ZU	Active	10.19.81.181	8082	N/A	V3.1.7build 2012...	10.19.81.254
002	DS-9018H4C-K8	Active	10.19.81.112	8080	N/A	V4.20.3008build 2...	10.19.81.254
003	DS-M77608-IV	Active	10.19.81.78	8080	N/A	V3.0.121822bu...	10.19.81.254
004	DS-M77608-IV	Active	10.19.81.77	8080	N/A	V3.0.121822bu...	10.19.81.254
005	DS-9612N-18	Active	10.19.81.81	8080	8443	V4.40.017build 2...	10.19.81.254
006	DS-P4454-WNM	Active	10.19.81.28	8080	N/A	V1.3.0build 202...	10.19.81.254
007	DS-6916U-DE	Active	10.19.81.221	8080	N/A	V1.3.0 build 200...	10.19.81.254
008	DS-2CD18146G0-I25	Active	10.19.81.223	8081	N/A	V3.5.81build 190...	10.19.81.254
009	DS-2CD18146G0-I25	Active	10.19.81.88	8081	N/A	V3.5.81build 190...	10.19.81.254
010	DS-4275T1M	Active	10.19.81.199	8081	N/A	V3.1.0build 2004...	10.19.81.254
011	DS-6020B-4FR	Active	10.19.81.60	8080	N/A	V3.5.13build 201...	10.19.81.254
012	DS-2CD12960G0-I25	Active	10.19.81.230	8081	N/A	V3.5.5build 2009...	10.19.81.254
013	DS-2CD2346FWD3-15	Active	10.19.81.137	8080	N/A	V3.5.13build 20...	10.19.81.254
014	DS-45071-ZU	Active	10.19.81.82	8031	N/A	V2.2.6build 2006...	10.19.81.254
015	DS-6308D-1	Active	10.18.84.200	8080	N/A	V1.0.3 build 150...	10.18.84.254
016	DS-2CD2712FWD-15	Active	10.19.81.53	8080	N/A	V3.6build 1612...	10.19.81.254
017	DS-2CD18146G0-I	Active	10.19.81.171	8080	N/A	V3.4.5build 1707...	10.19.81.254
018	DS-2CD18146G0-I	Active	10.19.81.236	8081	N/A	V3.5.738build 191...	10.19.81.254

Modify Network Parameters

- Enable DHCP
- Enable Hik-Connect
- Device Serial Number
- IP Address
- Port
- Enhanced SDK Service Port
- Subnet Mask
- Gateway
- IPv4 Address
- IPv4 Gateway
- IPv6 Prefix Length
- HTTP Ports

Security Verification


Administrator Password:

[Modify](#) [Forgot Password](#)


PART 2: INSTALL THE SOFTWARE

Go to the the downloaded zip file.


Extract the zip file.




Go to the extracted folder.




Open SADP installer (always 'run as administrator').




Agree to the terms.




Select 'English'.




Press 'Install'.



Press 'Completed'.




Open 'SADP Tool' (always 'run as administrator').



SADP Main Screen.

You can see all of your devices and device information, such as device type, IP address, firmware version, serial number etc.



Total number of online devices: 5

ID	Device Type	Status	IPv4 Address	Port	Enhance...	Software Version	IPv4 Gateway	HTTP...	Device Serial No.
001	DS-7608NI-I2/8P	Active	192.168	8000	8443	V4.60.005build 230307	192.168	80	DS-7608NI-I2/8P08201912
002	DS-2CD2386G2-ISU/SL	Active	192.168	8000	8443	V5.7.13build 230504	192.168	80	DS-2CD2386G2-ISU/SL202
003	DS-2CD2566G2-IS	Active	192.168	8000	8443	V5.7.13build 230504	192.168	80	DS-2CD2566G2-IS2022012
004	DS-2CD2386G2-ISU/SL	Active	192.168	8000	8443	V5.7.13build 230504	192.168	80	DS-2CD2386G2-ISU/SL202
005	DS-2CD2346G2-ISU/SL	Active	192.168	8000	8443	V5.7.13build 230504	192.168	80	DS-2CD2346G2-ISU/SL202

NOTE: TROUBLESHOOTING

If you don't see devices that you expect to see, you can try the following:

1. Restart PC.
2. Ensure you are connected to the same network as the device.
3. Connect via wired, instead of Wi-Fi.
4. Ensure all firewalls are turned off.
5. Ensure SADP is opened in administrator mode.