


38. HOW TO WATCH DOWNLOADED FOOTAGE USING VSPLAYER (JUNE 2025)


STEP 1

Open VSPlayer.



STEP 2

Confirm VSPlayer is open.



STEP 3

Click the + icon in the top left hand corner (Open File).



STEP 4

Go to the CCTV Downloads folder.



STEP 5

Go to the folder that contains the footage you want to watch.

Name



STEP 6

Find the selected video you want to watch.



✓ Driveway_West
_Cameras_Ca
meras_2025061
2130005_202...

STEP 7

Hover your mouse over the video and confirm it is a MP4 file (video) and not a JPG file (picture).




✓ Driveway_West
_Cameras_C
meras_2025061
2130005_202...

Driveway_West_Cameras_Cameras_2025061:
Item type: MP4 Video File (VLC)
Size: 57.8 MB
Availability status: Available on this device


STEP 8

Double click on the file to add it to the playlist.



STEP 9

Select the file in the playlist.



STEP 10

Press Play.



STEP 11

Press Pause.



STEP 12

Right click in the middle of the screen.


Go to Image Control.

Go to VCA Info Overlay.



STEP 13

Press Close All.



STEP 14

Press Play.



STEP 15

You can use the various controls at the bottom of the screen including:



Play



Pause



Stop



Single Frame Forward



Fast Forward (up to 16x)



Single Frame Backward



Fast Reverse (up to 16x)



Play in Reverse

STEP 16

You can add additional clips to the playlist by clicking the + icon in the top left hand corner (Open File).

