

206. HOW TO REBOOT THE INDOOR STATION **(JULY 2025)**

STEP 1

Go to the Home Screen.




STEP 2

Go to Settings.




STEP 3

Go to Advanced Settings.




STEP 4

Press Reboot Device



STEP 5

Press OK.



STEP 6

Wait 5 minutes.

STEP 7

Confirm intercom is rebooted.

