

211. HOW TO ENABLE HIK-CONNECT (JULY 2026)

STEP 1

Go to the Home Screen.




STEP 2

Go to Settings.




STEP 3

Go to Advanced Settings.




STEP 4

Go to Configuration.




STEP 5

Enter the admin password.




STEP 6

Go to Maintenance.




STEP 7

Go to Hik-Connect Service Settings.



STEP 8

Enable Hik-Connect.



STEP 9

Set your Verification Code.



STEP 10

Confirm the status is shown as 'Online'.

